Cowry Calgary - Crown Moulding Install

Top have 1/2" space

A

Mark on the crown moulding

B

Cutting angle

C

Crown moulding just nailed to the front frame

D

18 or 23 GA Nails

E